



International Glass Database System

INTERGLAD Ver. 7

NEW GLASS FORUM

International Glass Database System

INTERGLAD Ver. 7

User's Manual

May 2013

NEW GLASS FORUM

NEW GLASS FORUM

21-16, 3-chome, Hyakunin-cho, Shinjuku-ku, Tokyo 169-0073 JAPAN

TEL: +81-3-6279-2605 FAX: +81-3-5389-5003 <http://www.newglass.jp>

E-mail: interglad-qa@newglass.jp

<All rights reserved>

Contents of User's Manual for INTERGLAD Ver. 7

Chapter 1. Introduction

- 1.1 History of INTERGLAD
- 1.2 New features and improvements of INTERGLAD Ver. 7

Chapter 2. Outline

- 2.1 Contents and functions
- 2.2 Application types
- 2.3 User types
- 2.4 User requirements

Chapter 3. Basic procedures

System installation and initial setting

- A. Start-up
- B. Search for property database
- C. Analysis for property database
- D. Prediction and designing by property database
- E. Search and analysis for structure database
- F. Registration of user data and its use

Appendix

- 1. Multiple regression analysis with multiple-order polynomials
- 2. Data interpolation
- 3. Typical data items

Chapter 4 Detailed explanation of windows and operation

- 4.1 Main window and common features
- 4.2 Search for property database
- 4.3 Analysis for property database
- 4.4 Property prediction & material designing (composition optimization)
- 4.5 Structure Database
- 4.6 Registration of user data

Chapter 5 Examples of use

- 5.1 Search and analysis of property data
- 5.2 Property prediction by additivity equations
- 5.3 Property prediction & material designing by multiple regression analysis
- 5.4 Search and analysis of structure data

Chapter 6 Appendix

- 6.1 Additivity equation
- 6.2 Property equation
- 6.3 Table data
- 6.4 Curve data for glass-forming region
- 6.5 Glass ID list